

Sterile QuikBow®

for Intraoperative Traction



Step 2:
Turn the handle clockwise
as much as possible
for maximum tension across the wire

Step 1:
Use thumbs to **press the levers in**
to attach QuikBow® to 2mm
traction to pin



Stocked in:



Instructions for Use Video



Osi Table Adapter Video

Any questions, please contact: training@arbutusmedical.ca